



ST-4 Instruction Booklet



Strider **ST#4**



TABLE OF CONTENTS

Introduction	1
Important Precautions	2
Electromagnetic Interference and Warnings	3
Identification of Parts	6
Operating Your Scooter	10
Disassembling Your Scooter	12
Re-assembling Your Scooter	15
Charging the Batteries	16
Care and Maintenance	18
Troubleshooting	19
Technical Specifications	21

INTRODUCTION

Thank you and congratulations on purchasing your new Days Healthcare Ltd. Mobility Scooter.

We pride ourselves on providing safe and comfortable products. Our goal is to ensure your complete satisfaction. We sincerely hope you enjoy your Days Healthcare Ltd. Mobility Scooter.

Please read and observe all warnings and instructions provided in Instruction Booklet before you operate the various functions of this scooter. Also, please retain this booklet for future reference.

If you have any question, you can contact :

or your local dealer:



IMPORTANT PRECAUTIONS

- This scooter is designed for single person use only at any one time.
- Maximum User Weight is 135 kg / 300 lbs.
- Turn the key off before getting on or off your scooter.
- Always drive carefully with your feet on the floorboard and be aware of others in your area.
- Always use pedestrian crossings where possible. Take extreme care crossing roads.
- Do not drive on slopes exceeding 12 degrees, and take extreme care when turning on slopes.
- Do not use full power when turning.
- Do not drive the scooter unless the seat and the tiller are locked and secured in the driving position.
- Do not use the scooter if the rear anti-tip wheels are damaged or removed.
- A slow speed must always be used when ascending, descending or traversing a slope or incline and also on uneven terrain, ramps and soft or loose surfaces, such as gravel or grass.
- The scooter may not operate well in high humidity.
- Never put your scooter in freewheel whilst on a slope.
- Ensure you abide by any national traffic laws when using the scooter on paths and public highways.
- It is NOT recommended to use your scooter in wet environments as it may cause damage. Electronic equipment damaged by any liquid form is not covered under the warranty.

ELECTROMAGNETIC INTERFERENCE AND WARNINGS

CAUTION: It is very important that you read this information regarding the possible effects of Electromagnetic Interference on your motorized scooter.

Powered wheelchairs and motorized scooters may be susceptible to electromagnetic interference (EMI), which is interfering electromagnetic energy (EM) emitted from sources such as radio stations, TV stations, amateur radio (HAM) transmitters, two-way radios, and cellular phones. The interference (from radio wave sources) can cause the motorized scooter to release its brakes, move by itself, or move in unintended directions. It can also permanently damage the motorized scooter control system. The intensity of the interfering EM energy can be measured in volts per meter (V/m). Each motorized scooter can resist EMI up to a certain intensity. This is called its "immunity level." The higher the immunity level, the greater the protection will be. At this time, current technology is capable of achieving at least a 20 V/m immunity level, which would provide useful protection from the more common sources of radiated EMI. The immunity level of this motorized scooter model is 10 v/m.

There are a number of sources of relatively intense electromagnetic fields in the everyday environment. Some of these sources are obvious and easy to avoid. Others are not apparent and exposure is unavoidable. However, we believe that by following the warnings listed below, your risk to EMI will be minimized.

The sources of radiated EMI can be broadly classified into three types :

1. Hand-held portable transceivers (transmitters-receivers) with the antenna mounted directly on the transmitting unit. Examples include: citizens band (CB) radios, "walkie talkie," security, fire, and police transceivers, cellular telephones, and other personal communication devices.



Some cellular telephones and similar devices transmit signals while they are ON, even when not being used.

2. Medium-range mobile transceivers, such as those used in police cars, fire trucks, ambulances, and taxis. These usually have the antenna mounted on the outside of the vehicle.

3. Long-range transmitters and transceivers such as commercial broadcast transmitters (radio and TV broadcast antenna towers) and amateur (HAM) radios.



Other types of hand-held devices, such as cordless phones, laptop computers, AM/FM radios, TV sets, CD players, and cassette players, and small appliances, such as electric shavers and hair dryers, so far as we know, are not likely to cause EMI problems to your motorized scooter.

Motorized Scooter Electromagnetic Interference :

Because EM energy rapidly becomes more intense as one moves closer to the transmitting antenna (source), the EM fields from hand-held radio wave sources (transceivers) are of special concern. It is possible to unintentionally bring high levels of EM energy very close to the motorized scooter control system while using these devices. This can affect motorized scooter movement and braking. Therefore, the warnings listed below are recommended to prevent possible interference with the control system of the motorized scooter.

Warnings :

Electromagnetic interference (EMI) from sources such as radio and TV stations, amateur radio (HAM) transmitters, two-way radios, and cellular phones can affect motorized scooters. Following the warnings listed below should reduce the chance of unintended brake release or motorized scooter movement, which could result in serious injury.

1. Do not operate hand-held transceivers (transmitters-receivers), such as citizens band (CB) radios, or turn ON personal communication devices, such as cellular phones, while the motorized scooter is turned ON;
2. Be aware of nearby transmitters, such as radio or TV stations, and try to avoid coming close to them;
3. If unintended movement or brake release occurs, turn the motorized scooter OFF as soon as it is safe;

4. Be aware that adding accessories or components, or modifying the motorized scooter, may make it more susceptible to EMI; and.



There is no easy way to evaluate their effect on the overall immunity of the motorized scooter.

5. Report all incidents of unintended movement or brake release to the distributor listed on the inside front cover of this manual. Note whether there is a source of EMI nearby.

Important Information :

1. 20 volts per meter (V/m) is a generally achievable and useful immunity level against EMI (as of May 1994). The higher the level, the greater the protection.
2. The immunity level of this product is at least 20/Vm.

IDENTIFICATION OF PARTS

Before attempting to drive this scooter on your own, it is important that you familiarize yourself with the controls and how they operate.



Figure 1 - ST-4 Front View




Figure 2 -
ST-4 TOP CONTROL PANEL








Figure 3
ST-4 BACK VIEW

Function Of Parts :





- **MAIN SWITCH (A)** (See Fig. 4)
 1. Turn the key clockwise to ON to switch power on status.
 2. Turn the key counterclockwise to OFF to switch power off status.
- **SPEED CONTROL KNOB (B)** (See Fig. 5)
 1. Turn the speed control knob clockwise for faster speed.
 2. Turn the speed control knob counterclockwise for slower speed.



- **TOP CONTROL PANEL BUTTONS** (See Fig. 6)
 1. Left/Right Turn Signal-Press Right Turn Signal (1) button for turning right, press Left Turn Signal (2) button for turning left.
 2. Hazard Light Button-Press Hazard Light Button (3) to switch on Hazard Light, press the button again to switch off the Hazard Light.
 3. Horn Button-Press Horn Button (4) will buzz warning sound, stop tone by releasing button.
 4. Power Reserve Indicator (5)-Displays batteries electricity carrying capacity.
 5. Headlight Button-Press Headlight Button (6), headlight will light up. Press again to switch off.
 6. Hi/Lo Speed Switch allows speed to be changed from the normal maximum 12.8 kmph to half for pavement use.
- **THROTTLE CONTROL** (See Fig. 7)
 1. Lightly push on the right side throttle control lever (C) to move forward.
 2. Lightly push on the left side throttle control lever (D) to move backward.
 3. Release the throttle control lever and the powered scooter will quickly slow down to an immediate stop and the brake will engage.
 4. The throttle control lever can also be reversed.



- **ARMREST ADJUSTMENT** (See Fig. 8)
 1. Release Thumbscrew (E), to adjust the armrest's width; tighten to lock in the comfortable desired position.
- **ARM PAD ADJUSTMENT** (See Fig. 9)
 1. Adjust the handrail bolt's (F) height, to control the armrest's horizontal angle.
- **SEAT ADJUSTMENT** (See Fig. 10)
 1. Pull the seat rotation lever (G) up to adjust seat's turning angle, also to lift up the seat .
 2. Pull the seat sliding lever (H) up to adjust the seat to either go forward or backward to an appropriate position.



- **Freewheel Lever** (See Fig. 11)
 1. Before driving, engage the freewheel lever (J) by pressing down button (I) then pushing the lever (J) downward.
 2. The scooter can be pushed manually. To do this you must press down button (I) then push the freewheel lever (J) upwards to the N position.



Its extremely dangerous and forbidden to sit on the scooter when free-wheeling lever is disengaged and declining a slope.

- CIRCUIT BREAKER (See Fig. 12)
 - 1.If the scooter's circuit system malfunctions or over loaded, the circuit breaker (K) will automatically switch off the power to ensure safety.
 - 2.To reset system press the circuit breaker.
- TILLER ANGLE ADJUSTMENT (See Fig. 13)
 - 1.To adjust tiller angle by pushing down the tiller angle adjustment (L).



Do not hang any objects on the Tiller angle adjustment lever.




Figure 12




Figure 13

OPERATING YOUR SCOOTER

Before beginning your journey with your new scooter, make sure that the scooter is on a level surface and clear of any obstacles. Although your scooter is able to climb slopes it is safer to practice on a level surface.

You can make the following adjustments to increase your comfort when driving :

- adjust the seat height and location.
- adjust the armrest width.
- adjust the tiller to a comfortable position.

1. Before operating your scooter, check the following:

- the freewheel lever is engaged.
- the speed dial is at the picture of the turtle.

2. Sit on the scooter and turn on the key. All battery gauge LED lights should lit. The Self-Diagnostic Warning Light should not be flashing.

3. When your hands rest comfortably on the handle bar, the thumb control levers should be within reach. The right lever moves the scooter forward; the left one moves it in reverse. When you release the thumb lever, the scooter will stop.



This scooter has an automatic braking system. Release the thumb control and the brakes will engage.

4. Steering the scooter is done by turning tiller in the direction of intended travel

5. Practice driving the scooter in an area with no obstacles to familiarise yourself with the turning and starting/stopping operations Start at the slowest speed and drive forwards and backwards. As you become comfortable you can increase the speed by turning the speed dial towards the picture of the rabbit.

6. If the only two-battery gauge LED lights are lit, you should recharge the batteries as soon as possible.

7. If the scooter stops and does not function, locate the circuit breaker (M) in the storage area. Push it and try the scooter again.

8. When you stop driving the scooter, turn off the key before getting off.

9. When the scooter is not being used the batteries should be placed on charge.
See **CHARGING THE BATTERIES** on page 16.




Figure 14

Keep in mind these rules :

- Release the thumb levers and allow the scooter to stop completely before changing from forward to reverse, or reverse to forward.
- When negotiating a corner always turn slightly wider than necessary as the rear wheels take a sharper and more direct route and not that of the front steering wheels.
- A slow speed must always be used when ascending, descending or traversing a slope or incline and also on uneven terrain, ramps and soft or loose surfaces, such as gravel or grass.

Other Operating Information :

Hill Climbing: You may need to use a higher speed going up on slopes. For a higher speed, set the speed control knob in the proximity of the rabbit.

Down Slopes: To proceed down steep slopes slowly, set the speed control in the proximity of the turtle. This enables driver control, as the closer the speed control is set toward the turtle, the slower the scooter will travel. However, this scooter will not self accelerate down hills due to the automatic braking taking effect should you attempt to drive too fast.

Kerb Climbing: Approach slowly at right angles to the curb. A slight angle is permissible with a 4-wheel scooter. Do not attempt curb climbing greater than a 50mm curb.

Vertical limit approach approximately : 5cm

Acceptable gap width approximately : 22cm



When driving, proceed straight forward slowly pass through the gap.




Figure 15




Figure 16

If the scooter breaks down and must be moved, get off the scooter, pull the free-wheeling lever, move the scooter slowly to a safe location, and push the free-wheeling lever back downward to engage.






As a safety feature, an automatic speed reducer engages if the scooter is pushed quickly when the Free-Wheeling Lever is disengaged. This standard feature is specifically created for down slopes.

DISASSEMBLING YOUR SCOOTER



Taking apart your scooter enables you to save space when keeping it in storage or to carry it along in your vehicle when going away from home. Having the scooter disassembled is easier than ever since no tools are required. Please follow these steps

Remove the seat by pull the Seat Rotation Lever (N) up and then lift off. (See Fig. 17) Lift up the Storage Cover (O). (See Fig. 18) and detach the Rear Lighting Wiring Harnesses (P). (See Fig. 19) Remove the Rear Shroud (Q) gently which is held by Velcro.(See Fig. 20)





Detach the Main Wiring Harness (R) from the scooter. (See Fig. 21)

Unstrap the Velcro Band (S) that holds the batteries. (See Fig. 22)





Unplug both Battery Cables (T) and remove the Batteries (U). (See Fig. 23 & 24)





Detach the front and rear sections by holding the Seat Post (V) with one hand and the other hand pushing the release lever to the rear of the scooter. Lift the seat post to separate the Front Frame Assembly (W) from the rear frame assembly. (See Fig. 25)

Disassemble Front Basket (X1). (See Fig. 26)




Push down the Tiller Angle Adjustment (Y) to fold the tiller in a lower position. (See Fig. 27)
Once all the parts have been disassembled, you are now able to put the pieces in storage or in a vehicle for transportation. (See Fig. 28)



RE-ASSEMBLING YOUR SCOOTER

To assemble the scooter, you can repeat the disassembly directions in reverse. Abbreviated directions are given below. Refer to the figures on pages 12-13 to locate the parts.

1. Using the tiller angle adjustment, unfold the tiller in an upright position. Place the front basket on the tiller.
2. Hold the seat post and align the Curved Locking Brackets (Z) on the front frame assembly with the bar on the rear frame assembly.



3. While holding the seat post, slowly pivot the rear frame assembly forward until the release lever locks.
4. Attach the main wire harness.
5. Place the two batteries and use the Velcro strap to secure them in place.
6. Attach the battery cable plugs.
7. Place the rear shroud on.
8. Attach all rear lighting harnesses.
9. Place the storage cover on.
10. Install the seat by pulling the seat rotation lever up to allow the seat to drop into the locked position.

CHARGING THE BATTERIES

Batteries must be charged before using the scooter for the first time and should be recharged after each day use. You will need the scooter and the battery charger.



Each country may supply different charger. The charging procedure may be different from below.

If you require more details, please contact your authorized dealer.



Be sure the scooter key is in the OFF position




Figure 30

1. Insert battery charger cord into the charger connector on the charger output. Refer to above figure for correct position
2. Plug the other end of the battery charger cable into a standard electrical outlet.
3. Turn the power on. Normally, The LED (Power) Light will turn on when electric current passes.
4. Charging starts. During charging, LED (Charge) will indicate orange light, when it turns to green light, that means well-charged.
5. LED indication
 - LED(POWER) - GREEN LIGHT ON : Power On.
 - LED(CHARGE) - ORANGE LIGHT ON : Charging / GREEN LIGHT ON : Fully Charged
6. Charger Trouble Shooting
 - (A) If LED (POWER) light is off
 - Check the input voltage (115V/230V) is the same as you adjust.
 - If light is still off, please check and repair the battery charger.
 - (B) If LED (CHARGE) light is off
 - Check to see clips connection is correct.
 - If the battery is fully charged, the LED (CHARGE) light will be off.
 - If light is still off, the battery may be defective.
 - (C) If ORANGE light can turn to GREEN
 - The battery can not be charged. Please check and recover it.
 - (D) If ORANGE light turns to GREEN immediately
 - Check to see the battery is fully charged, if not, The battery may be defective
Check and recover it.



The time needed to recharge will vary depending on the depletion of the batteries. Charging for longer than necessary will not harm the batteries. They cannot be overcharged.

Keep in mind these rules :

- Fully charge batteries at least once a month, more if you use the scooter regularly. Charge after each trip exceeding 3 kilometers / 1.86 miles.
- If storing your scooter for some time (one month or more) make sure that the batteries are fully charged, and on returning, charge them again before using the scooter.

Batteries will only give the maximum performance after the scooter has been used, and the batteries have been recharged up to 10 times.

For safety, please follow the guidelines below.

1. DO NOT use the charger if the power cord is damaged.
2. DO NOT use an extension cord when charging your batteries. A risk of fire and/or electric shock could be encountered.
3. DO NOT take apart the charger, as this will void the warranty.

CARE AND MAINTENANCE

Taking care of your scooter will keep it in top-notch condition. It is recommended that you have your dealer to provide preventative maintenance service of your scooter on a regularly basis. Here are a few maintenance guidelines:

BODY COVER: If your scooter is dirty, use a damp or soapy cloth to wipe it down.

Do not use running water to wash or rinse the scooter in order to protect the electrical parts. Polish with an automotive liquid polish.

SEAT AND ARMREST: Using a damp cloth helps clean the upholstery. Please note that using the scooter outdoors can lead to sun damage of the upholstery material. Since this is a normal wear and tear condition, it is not covered under the warranty.

An authorized dealer should do all maintenance and repair of your scooter that relates to electronics, batteries, motor parts, and tyres.

Also between uses, your scooter is best stored in a dry location at room temperature.

TROUBLESHOOTING

To check the Self-Diagnostic Warning Light, turn on the key and count the number of flashes.

Flash Code/Fault	Impact on Scooter	Notes
1. Battery needs recharging	Will drive	Battery charge is running low. Recharge the batteries as soon as possible.
2. Battery voltage too low	Drive inhibited	Battery charge is empty. Recharge the batteries. If the scooter is left off for a few minutes, battery charge might recover enough to allow driving for a short time.
3. Battery voltage too high	Drive inhibited	Battery charge is too high. If a charger is plugged in, unplug it or turn the Charge/Run switch to Run. Scooters powered by RHINO charge the batteries when travelling down slopes or decelerating. Excessive charging in this manner can cause this fault. Turn the scooter power off then on again. If necessary, reduce speed when descending the slope.
4. Current limit time-out	Drive inhibited	The scooter has drawn too much current for too long, possibly because the motor has been over-worked, jammed or stalled. Turn the scooter power off, leave for a few minutes, and then turn the power back on again. The controller has detected a shorted motor. Check the loom for shorts and check the motor. Contact your service agent.
5. Brake fault	Drive inhibited	Check that the park-brake release lever is in the engaged position. Check that the motor/park-brake connector is plugged in firmly. The park-brake coil or wiring is faulty. Check the park brake and wiring for open or short circuits. If necessary, unplug the motor/park-brake connector and check that all four pins are in the correct position. If this flash code does not appear until the throttle has been moved out of neutral, check for a short in the park-brake circuit. If this flash code appears at power-up, check for an open circuit in the park-brake circuit. Contact your service agent.
6. Out of neutral at power-up	Drive inhibited	Thumb lever not in neutral position when turning key switch on. Return Thumb lever to neutral, turn power off, and back on again. Throttle may need to be re-calibrated (see Section 4.2.3). Check throttle wiring.
7. Speed VR error	Drive inhibited	Thumb lever or its wiring is faulty. Check for open or short circuits. Thumb lever may not be correctly set up. Contact your service agent.
8. Motor volts error	Drive inhibited	The motor or its wiring is faulty. Check for open or short circuits. Contact your service agent.
9. Other internal errors	Drive inhibited	Contact your service agent.

Other Problems :

- Scooter will not move when the key is turned on:
 1. Check the power reserve indicator on the control panel. All the LED lights should be on.
 2. Check the Self-Diagnostic Warning Light. It should be steady. If it is flashing, see chart on page 19 for problem identification.
 3. Check all electrical connections to ensure they are tight.
 4. If none of these correct the problem, contact your authorized dealer.

- If you have charged your scooter for over 10 hours and the light on the charger does not change to green, then please contact your authorized dealer.

Please note that your scooter is equipped with a controller that constantly checks the drive system for a safe and enjoyable ride. If an error occurs, the control panel will provide you an indication of the problem by way of flashing lights.

TECHNICAL SPECIFICATIONS

Overall Length	1290 mm / 50.8"
Overall Width	625 mm / 24.6"
Overall Height	980 mm / 36.6"
Wheels : Front	290 mm / 11"
Wheels : Rear	290 mm / 11"
Weight w/ Batteries	97.9 kg / 215.8 lbs
Max. Speed	12.8 kmph / 7.95 mph
Maximum Weight Capacity	150 kg / 330 lbs
Ground Clearance	87 mm / 3.4"
Maximum Safe Slope	12 degree
Kerb Climbing	50 mm / 2"
Turning Radius	1565 mm / 61.8"
Suspension	Front & Rear
Brake	Electro-Mechanical
Seat Type	Premium Upholstery Mid-Back w/ Headrest Swivel Seat-Sliding Adjustment
Seat Width	455 mm / 18"
Motor Size	700W 5900 r.p.m
Battery	(2) 12V. 50Ah
Weight Of Batteries	31.26 kg / 69 lbs
Weight of Heaviest Component	26.3 kg / 58 lbs
Travel Range	40 km / 25 Miles
Battery Charger	5A Off Board
Electronics	On / Off Key Switch, Battery Level Indicator, Speed Control Knob

*Subject to change without notice.